

## ACCESSORIES

## INK/DOCTORING CUP "ClipLock®"



- 
- 
- 
- 
- ACCESSORIES
- 

- "ClipLock®" Re-filling without removing ✓
- Ideal in connection with ink tubes from TAMPOPRINT® ✓
- Washable with "RM" cleaning agent in spray washing unit ✓
- At the same price as the present plastic version ✓

*technologies for your future*  
*made in germany*



Tampon printing machines  
ALFALAS® Laser Systems  
Automations  
DMD® Industrial Inkjet Systems

## "ClipLock®" -

### Ink/doctoring cup with lid

You want to see whether the ink in your ink/doctoring cup is still in order?

You want to re-fill ink or solvent into your ink/doctoring cup?

This required so far the removal of the ink/doctoring cup with the cliché from the printing machine.

Now there's an end of it!

The magic word is "ClipLock®".

"ClipLock®" allows to open the ink/doctoring cup while it is still in the machine and makes an immediate check of the ink condition possible.

The "ClipLock®" closure uses the complete ink/doctoring cup diameter as an opening. The lower height of the "ClipLock®" allows a considerably improved economy of set-up time and ink consumption; even the downtimes during production will be clearly reduced since the removal of the ink/doctoring cup for re-filling of ink is not necessary any more.

#### Option:



Optimum handling with the gripper for the lid ClipLock®

Dealer:

Thanks to the user-friendly pre-centering and the coloured lid a faulty operation when closing the lid will be avoided. The handling will become much easier thanks to our gripper for the lid "ClipLock®".

We have attached great importance to the ease of cleaning of the "ClipLock®" closure system which was a major criterion during development and which can be found both in the material and the design.

A glass stirring staff and a solvent pipette will be delivered with the Ink/doctoring cup "ClipLock®".

Ink/doctoring cup		Part No.
ClipLock®	Ø 60 mm	09 00 33
ClipLock®	Ø 90 mm	09 00 34

Option		Part No.
Gripper for lid ClipLock®	Ø 60 mm	09 01 67
Gripper for lid ClipLock®	Ø 90 mm	09 01 68

Spare parts		Part No.
Lid ClipLock®	Ø 60 mm	09 01 65
Lid ClipLock®	Ø 90 mm	09 01 66
Glass stirring staff	Ø 5 x 200 mm	09 01 69
Solvent Pipette	3 ml	09 01 75

Available as of September 2009 !

#### Scope of supply:



GLASS STIRRING STAFF

SOLVENT PIPETTE

You can contact our sales team on:

Mon - Thurs: 7 a.m. - 4 p.m.

Fri: 7 a.m. - 12.30 p.m.

Fax: +49 7150 928-425

E-mail: [salesparts@tampoprint.de](mailto:salesparts@tampoprint.de)



#### TAMPOPRINT® AG

Lingwiesenstraße 1

70825 Korntal-Münchingen, GERMANY

☎ +49 7150 928-0

Fax: +49 7150 928-400

E-Mail: [info@tampoprint.de](mailto:info@tampoprint.de)

#### "Ventes et Affaires Françaises"

☎ +49 7150 928-144

Fax: +49 7150 928-432

E-Mail: [ventes@tampoprint.de](mailto:ventes@tampoprint.de)

http: [www.tampoprint.de](http://www.tampoprint.de)

#### TAMPOPRINT® INTERNATIONAL CORP.

1400 26th Street, Vero Beach, FL 32960, USA

☎ +1 772 778-8896, 800 810-8896

Fax: +1 772 778-8289

E-Mail: [sales@tampoprint.com](mailto:sales@tampoprint.com)

http: [www.tampoprint.com](http://www.tampoprint.com)

#### TAMPOPRINT® IBERIA S.A.U.

c/Caspe 127-135 local B, 08013 Barcelona, SPAIN

☎ +34 93 2327161

Fax: +34 93 2471500

E-Mail: [tampoprint@tampoprint.es](mailto:tampoprint@tampoprint.es)

http: [www.tampoprint.es](http://www.tampoprint.es)

ORIGINAL

**TAMPOPRINT®**

The reproduction of trademarks and brands used in this brochure, even if not explicitly expressed, does not justify the assumption that such names or symbols may be considered as free as defined by the Trademark Act and may therefore freely be used. The rights are the property of the respective owner.

TAMPOPRINT® products are permanently updated to keep pace with the latest technological developments. For this reason, figures and descriptions are non-binding. Manufactured according to EC Directive 98/37/EC.

Subject to alterations! ©Copyright